

# MOTOR CONTROL

# FAULT FINDING ACCESSORIES

## Chain Hoist Encoder tester



The tester can save hours of cable tracing. Designed to test most makes of chain hoist encoder. Simply plug into the encoder cable and run the hoist. Alternately flashing LEDs indicate a good encoder signal.

## Mains power Phase direction test plug



For use as a test and fault finding aid in any situation where correct 3 phase mains rotation is critical. Simply connect the test plug into an outlet and switch on the power. The green LED lights for correct rotation and the red for incorrect.

## CM type chain hoist Motor direction test plug



Designed specifically for the CM hoist control, connect the test plug into a motor control out-let. Select a direction and press 'GO'. If the green LED lights a hoist would travel up, if the red LED lights a hoist would travel down.

**All the testers are designed to be as easy to use as possible**

**No special training required**

**Save many hours of cable and circuit tracing**

**They can be used with equipment in place**

**Manufactured with heavy duty components to survive the toughest tour**

**Designed to make life easier**