


FITTING A SMARTSAFE



CABLE DESTINATION

RED	TRANSFORMER LUG:RED
BLACK	TRANSFORMER LUG:BLA
WHITE	TRANSFORMER LUG:WHI
PINK	UPPER LIMIT SWITCH
YELLOW	LOWER LIMIT SWITCH
PINK	UP CONTACTOR
YELLOW	DOWN CONTACTOR

TERMINAL BOARD	
RED	Lug: RED
BLACK	Lug: BLA
WHITE	Lug: WHI
PINK	Upper Limit
YELLOW	Lower Limit
PINK	Up Contactor
YELLOW	Down Contactor

SMARTSAFE

Test: _____ Date: _____



- 1/ Remove the cable marked P that runs from lower limit switch to down contactor.
- 2/ Remove the cable marked T that runs from upper limit switch to up contactor.
- 3/ Fit loom assemble (red, black, white, pink and yellow) through motor from contactor to transformer terminal board. The other pink and yellow go to the contactors. Pink replacing T and yellow replacing P.
- 4/ Make connection as instructed above.